



Advanced simple Inverter

iMaster-E1

CAUTION

Thank you for purchasing our iMaster-E1 inverters.

- This product is designed to drive a three-phase induction motor. Read through this Brief manual and be familiar with the handling procedure for correct use.
 - Improper handling might result in incorrect operation, a short life, or even a failure of this product as well as the motor.
 - Deliver this quick guide to the end user of this product. Keep this in a safe place until this product is discarded.
 - For more details, refer to the instruction manual on website. (www.adtech21.com)
-

SAFETY

FOR THE BEST RESULTS WITH iMaster-E1 SERIES INVERTER, READ THIS MANUAL AND ALL OF THE WARNING SIGN ATTACHED TO THE INVERTER CAREFULLY BEFORE INSTALLING AND OPERATING IT, AND FOLLOW THE INSTRUCTION EXACTLY. KEEP THIS MANUAL HANDY FOR YOUR QUICK REFERENCE.

DEFINITIONS AND SYMBOLS

A SAFETY INSTRUCTION (MESSAGE) IS GIVEN WITH A HAZARD ALERT SYMBOL AND A SIGNED WORD, **WARNING** or **CAUTION**.

EACH SIGNAL WORD HAS THE FOLLOWING MEANING THROUGHOUT THIS MANUAL.



THIS SYMBOL MEANS HAZARDOUS HIGH VOLTAGE. IT USED TO CALL YOUR ATTENTION TO ITEMS OR OPERATIONS THAT COULD BE DANGEROUS TO YOU OR OTHER PERSONS OPERATING THIS EQUIPMENT. READ THESE MESSAGES AND FOLLOW THESE INSTRUCTIONS CAREFULLY.




THIS IS THE "SAFETY ALERT SYMBOL". THIS SYMBOL IS USED TO CALL YOUR ATTENTION TO ITEMS OR OPERATIONS THAT COULD BE DANGEROUS TO YOU OR OTHER PERSONS OPERATING THIS EQUIPMENT. READ THESE MESSAGES AND FOLLOW THESE INSTRUCTIONS CAREFULLY.



WARNING INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, CAN RESULT IN SERIOUS INJURY OR DEATH.



CAUTION INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, CAN RESULT IN MINOR TO MODERATE INJURY, OR SERIOUS DAMAGE OF PRODUCT.

THE MATTERS DESCRIBED UNDER  **CAUTION** MAY, IF NOT AVOIDED, LEAD TO SERIOUS RESULTS DEPENDING ON THE SITUATION. IMPORTANT MATTERS ARE DESCRIBED IN **CAUTION** (AS WELL AS WARNING), SO BE SURE TO OBSERVE THEM.

NOTE NOTES INDICATE AN AREA OR SUBJECT OF SPECIAL MERIT, EMPHASIZING EITHER THE PRODUCT'S CAPABILITIES OR COMMON ERRORS IN OPERATION OR MAINTENANCE.



HAZARDOUS HIGH VOLTAGE

MOTOR CONTROL EQUIPMENT AND ELECTRONIC CONTROLLERS ARE CONNECTED TO HAZARDOUS LINE VOLTAGE.

WHEN SERVICING DRIVES AND ELECTRONIC CONTROLLERS, THERE MIGHT BE EXPOSED COMPONENTS WITH CASES OR PROTRUSIONS AT OR ABOVE LINE POTENTIAL.

EXTREME CARE SHOULD BE TAKEN TO PROTECT AGAINST SHOCK. STAND ON AN INSULATING PAD AND MAKE IT A HABIT TO USE ONLY ONE HAND WHEN CHECKING COMPONENTS.

ALWAYS WORK WITH ANOTHER PERSON IN CASE AN EMERGENCY OCCURS. DISCONNECT POWER BEFORE CHECKING CONTROLLER OR PERFORMING MAINTENANCE.

BE SURE EQUIPMENT IS PROPERLY GROUNDED. WEAR SAFETY GLASSES WHENEVER WORKING ON AN ELECTRIC CONTROLLER OR ROTATING ELECTRICAL EQUIPMENT.

PRECAUTION



WARNING : THIS IS EQUIPMENT SHOULD BE INSTALLED, ADJUSTED AND SERVICED BY QUALIFIED ELECTRICAL MAINTENANCE PERSONAL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE EQUIPMENTS AND THE HAZARDS INVOLVED. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULTS IN BODILY INJURY.



WARNING : THE USER IS RESPONSIBLE FOR ENSURING THAT ALL DRIVEN MACHINERY, DRIVE TRAIN MECHANISM NOT SUPPLIED BY ADT Co., Ltd. AND PROCESS LINE MATERIAL ARE CAPABLE OF SAFE OPERATION AT AN APPLIED FREQUENCY OF 150% OF THE MAXIMUM SELECTED FREQUENCY RANGE TO THE AC MOTOR. FAILURE TO DO SO CAN RESULT IN DESTRUCTION OF EQUIPMENT AND INJURY TO PERSONNEL SHOULD A SINGLE POINT FAILURE OCCUR.



WARNING : FOR PROTECTION, INSTALL AN EARTH LEAKAGE BREAKER WITH A HIGH FREQUENCY CIRCUIT CAPABLE OF LARGE CURRENTS TO AVOID AN UNNECESSARY OPERATION. THE GROUND FAULT PROTECTION CIRCUIT IS NOT DESIGNED TO PROTECT PERSONAL INJURY.



CAUTION : HEAVY OBJECT. TO AVOID MUSCLE STRAIN OR BACK INJURY, USE LIFTING AIDS AND PROPER LIFTING TECHNIQUES WHEN REMOVING OR REPLACING.



CAUTION : THESE INSTRUCTIONS SHOULD BE READ AND CLEARLY UNDERSTOOD BEFORE WORKING ON iMaster-E1 SERIES EQUIPMENT.



CAUTION : PROPER GROUNDS, DISCONNECTING DEVICES AND OTHER SAFETY DEVICES AND THEIR LOCATION ARE THE RESPONSIBILITY OF THE USER AND ARE NOT PROVIDED BY ADT Co., Ltd..



CAUTION : BE SURE TO CONNECT A MOTOR THERMAL SWITCH OR OVERLOAD DEVICES TO THE iMaster-E1 SERIES CONTROLLER TO ASSURE THAT INVERTER WILL SHUT DOWN IN THE EVENT OF AN OVERLOAD OR AN OVERHEATED MOTOR



CAUTION: ROTATING SHAFTS AND ABOVE GROUND ELECTRICAL POTENTIALS CAN BE HAZARDOUS. THEREFORE, IT IS STRONGLY RECOMMENDED THAT ALL ELECTRICAL WORK CONFORM TO THE NATIONAL ELECTRICAL CODES AND LOCAL REGULATIONS. ONLY QUALIFIED PERSONNEL SHOULD PERFORM INSTALLATION, ALIGNMENT AND MAINTENANCE. FACTORY RECOMMENDED TEST PROCEDURES, INCLUDE IN THE BRIEF MANUAL, SHOULD BE FOLLOWED. ALWAYS DISCONNECT ELECTRICAL POWER BEFORE WORKING ON THE UNIT.

NOTE : POLLUTION DEGREE 2

THE INVERTER MUST BE USED IN THE ENVIRONMENT OF THE POLLUTION DEGREE 2. TYPICAL CONSTRUCTIONS THAT REDUCE THE POSSIBILITY OF CONDUCTIVE POLLUTION ARE,

- 1) THE USE OF AN UNVENTILATED ENCLOSURE.
- 2) THE USE OF A FILTERED VENTILATED ENCLOSURE WHEN THE VENTILATION IS FAN FORCED THAT IS, VENTILATION IS ACCOMPLISHED BY ONE MORE BLOWERS WITHIN THE ENCLOSURE THAT PROVIDE A POSITIVE INTAKE AND EXHAUST.

CAUTION FOR EMC (ELECTROMAGNETIC COMPATIBILITY)

TO SAFETY THE EMC DIRECTIVE AND TO COMPLY WITH STANDARD, FOLLOWS THE CHECKLIST BELOW.



WARNING

THIS EQUIPMENT SHOULD BE INSTALLED, ADJUSTED, AND SERVICED BY QUALIFIED PERSONAL FAMILIAR WITH CONSTRUCTION AND OPERATION OF THE EQUIPMENT AND THE HAZARDS INVOLVED.

FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

1. THE POWER SUPPLY TO iMaster-E1 INVERTER MUST MEET THESE SPECIFICATIONS
 - a. VOLTAGE FLUCTUATION $\pm 10\%$ OR LESS.
 - b. VOLTAGE IMBALANCE $\pm 3\%$ OR LESS.
 - c. FREQUENCY VARIATION $\pm 4\%$ OR LESS.
 - d. VOLTAGE DISTORTION THD = 10% OR LESS
2. INSTALLATION MEASURE :
 - a. USE A FILTER DESIGNED FOR iMaster-E1 INVERTER
3. WIRING
 - a. SHIELDED WIRE (SCREENED CABLE) IS REQUIRED FOR MOTOR WIRING, AND THE LENGTH MUST BE LESS THAN 20 METERS.
 - b. THE CARRIER FREQUENCY SETTING MUST BE LESS THAN 5KHZ TO SATISFY EMC REQUIREMENTS.
 - c. SEPARATE THE MAIN CIRCUIT FROM THE SIGNAL/PROCESS CIRCUIT WIRING.
 - d. IN CASE OF REMOTE OPERATING WITH CONNECTOR CABLE, THE INVERTER DOES NOT CONFORM TO EMC
4. ENVIRONMENTAL CONDITIONS – WHEN USING A FILTER, FOLLOW THESE GUIDELINES:
 - a. AMBIENT AIR TEMPERATURE : -10 - +50°C
 - b. HUMIDITY : 20 TO 90% RH(NON-CONDENSING)
 - c. VIBRATION : 5.9 M/S² (0.6G) 10 – 55HZ (iMaster-E1-0.4~3.7kW)
 - d. LOCATION : 3,280 FEET OR LESS ALTITUDE, INDOORS.
(NO CORROSIVE GAS OR DUST)

CONFORMITY TO THE LOW VOLTAGE DIRECTIVE (LVD)

THE PROTECTIVE ENCLOSURE MUST CONFORM TO THE LOW VOLTAGE DIRECTIVE.
THE INVERTER CAN CONFORM TO THE LVD BY MOUNTING INTO A CABINET OR BY ADDING
COVERS AS FOLLOWS.

1. CABINET AND COVER

THE INVERTER MUST BE INSTALLED INTO A CABINET WHICH HAS THE PROTECTION DEGREE
OF TYPE IP2X.

IN ADDITION THE TOP SURFACES OF CABINET ARE EASILY ACCESSIBLE SHALL MEET AT
LEAST THE REQUIREMENTS OF THE PROTECTIVE TYPE IP4X, OR WHICH IS CONSTRUCTED TO
PREVENT SMALL OBJECTS FROM ENTERING INVERTER.




Fig 1. INVERTER CABINET

General Safety Information

1. Installation

CAUTION

- Be sure to install the unit on flame resistant material such as metal. Otherwise, there is a danger of fire.
- Be sure not to place anything highly flammable in the vicinity. Otherwise, there is a danger of fire.
- Do not carry unit by top cover, always carry by supporting base of unit. There is a risk of falling and injury.
- Be sure not to let foreign matter enter inverter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc. Otherwise, there is a danger of fire.
- Be sure to install inverter in a place which can bear the weight according to the specifications in the text. (Chapter 2. Installation) Otherwise, it may fall and there is a danger of injury.
- Be sure not to install and operate an inverter which is damaged or has parts which are missing. Otherwise, there is a danger of injury.
- Be sure to install the inverter in an area which is not exposed to direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature, high in humidity or to have dew condensation, as well as places with dust, corrosive gas, explosive gas, highly flammable gas, grinding-fluid mist, salt damage, etc. Otherwise, there is a danger of fire.

General Safety Information

2. Wiring

WARNING

- Be sure to ground the unit.
Otherwise, there is a danger of electric shock and/or fire.
- Wiring work should be carried out by qualified electricians.
Otherwise, there is a danger of electric shock and/or fire.
- Implement wiring after checking that the power supply is off.
Otherwise, there is a danger of electric shock and/of fire.
- After installing the main body, carry out wiring.
Otherwise, there is a danger of electric shock and/or injury.

CAUTION

- Applicable to three phase input only
- Make sure that the input voltage is:
Three phase 200 to 240V 50/60Hz
Three phase 380 to 480V 50/60Hz
- Be sure not to single phase the input.
Otherwise, there is a danger of fire.
- Be sure not to connect AC power supply to the output terminals(U, V, W).
Otherwise, there is a danger of injury and/or fire and/or damage to unit.
- Be sure not to connect a resistor to the DC terminals(P, RB) directly.
Otherwise, there is a danger of fire and/or damage to unit.
- Be sure to install an earth leakage breaker or the fuse(s) which is(are) the same phase as the main power supply in the operation circuit.
Otherwise, there is a danger of fire and/or damage to unit.
- As for motor leads, earth leakage breakers, and electromagnetic contactors, be sure to use equivalent ones with the specified capacity(rated).
Otherwise, there is a danger of fire and/or damage to unit.
- Do not stop operation by switching off the electromagnetic contactors on the primary or secondary sides of the inverter.
Otherwise, there is a danger of injury and/or machine breakage.
- Fasten the screws to the specified torque. Check so that there is no loosening of screws.
Otherwise, there is a danger of fire and/or injury to personnel.

General Safety Information

3. Control and operation

WARNING

- Be sure to turn on the power supply with the front case is closed. While the inverter is energized, be sure not to open the front case. Otherwise, there is a danger of electric shock.
- Be sure not to operate the switches with wet hands. Otherwise, there is a danger of electric shock.
- While the inverter is energized, be sure not to touch the inverter terminals even while the unit is not running. Otherwise, there is a danger of electric shock.
- If the retry mode is selected, it may suddenly restart during the trip stop. Be sure not to approach the equipment. (Be sure to design the equipment so that personnel safety will be secured even if equipment restarts.) Otherwise, there is a danger of injury.
- Even if the power supply is cut for a short period of time, the inverter may restart operation after the power supply is restored if the operation command is given. If a restart may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery. Otherwise, there is a danger of injury.
- The stop key is valid only when a function is on. Ensure that there is a hard wired emergency stop that is separate from the stop key of the inverter. Otherwise, there is a danger of injury.
- With the operation command on, if the alarm reset is ordered, the inverter can restart suddenly. Be sure to set the alarm reset after checking the operation command is off. Otherwise, there is a danger of injury.
- Be sure not to touch the inside of the energized inverter or to put a shorting bar into it. Otherwise, there is a danger of electric shock and/or fire.

General Safety Information

CAUTION

- The cooling fins will have a high temperature. Be sure not to touch them.
Otherwise, there is a danger of getting burned.
- Low to high speed operation of the inverter can be easily set. Be sure to operate it after checking the tolerance of the motor and machine.
Otherwise, there is a danger of injury.
- Install an external breaking system if needed.
Otherwise, there is a danger of injury.
- If a motor is operated at a frequency outside of the standard setting value (50Hz/60Hz), be sure to check the speeds of the motor and the equipment with each manufacturer, and after getting their consent, operate them.
Otherwise, there is a danger of equipment breakage.
- Check the following before and during the test run.
Was the direction of the motor correct?
Did the inverter trip for on acceleration or deceleration?
Were the RPM and frequency motor correct?
Were there any abnormal motor vibrations or noises?
Otherwise, there is a danger of machine breakage.
- The AC reactor must be installed when the power is not stable. If not, inverter can be broken.

4. Maintenance, inspection and part replacement

WARNING

- After turning off the input power supply, do not perform the maintenance and inspection for at least 10 minutes.
Otherwise, there is a danger of electric shock.
- Make sure that only qualified persons will perform maintenance, inspection and/or part replacement.
(Before starting the work, remove metallic objects(wristwatch, bracelet, etc.) from a worker.
(Be sure to use insulated tools.) Otherwise, there is a danger of electric shock and/or injury.

5. Others

WARNING

- Never modify the unit.
Otherwise, there is a danger of electric shock and/or injury.

CONTENTS

1. GENERAL DESCRIPTION	1-1
1.1 Inspection upon Unpacking	1-1
1.1.1 Inspection of the unit	1-1
1.1.2 Brief manual	1-1
1.2 Questions and Warranty of the Unit	1-2
1.2.1 Questions on Unit	1-2
1.2.2 Warranty for the unit	1-2
2. Installation and Wiring	2-1
2.1 Installation	2-1
2.1.1 Installation	2-2
2.2 Wiring	2-3
2.2.1 Terminal Connection Diagram (sink type)	2-4
2.2.2 Main circuit wiring	2-7
2.2.3 Terminal connection diagram	2-8
3. Operation	3-1
4. Parameter Code List	4-1
4.1 About Digital Operator	4-1
4.1.1 Name and contents of each part of Standard-type digital operator	4-1
4.1.2 Key Definition and Operation of "SHIFT"	4-4
4.2 Function List	4-5
4.2.1 Monitor Mode (d-group) Display	4-5
4.2.2 Basic Function Mode of F Group	4-6
4.2.3 Expanded Function Mode of A Group	4-7
4.2.4 Expanded function mode of b group	4-16
4.2.5 Expanded Function Mode of C Group	4-21
4.2.6 Expanded Function mode of H Group	4-24
5. Protective function	5-1
6. Specification	6-1
6.1 Standard specification list	6-1
6.2 Dimension	6-4

1. GENERAL DESCRIPTION

1.1 Inspection upon Unpacking

1.1.1 Inspection of the unit

Please open the package, remove the inverter, please check the following items.
If you discover any unknown parts or the unit is damaged, please contact ADT Co., Ltd.

- (1) Make sure that the package contains one operation manual for the inverter.
- (2) Make sure that there was no damage (broken parts in the body) during transportation of the unit.
- (3) Make sure that the product is the one you ordered by checking the label specification.




Fig1-1 Outlook of iMaster-E1 Inverter (1frame, 2frame, 3frame)




Fig1-2 Contents of Specification label

1.1.2 Brief manual

This Brief manual is the manual for the iMaster-E1 inverters.

Before operation of the inverter, read the manual carefully. After reading this manual, keep it on hand for future reference

1.2 Questions and Warranty of the Unit

1.2.1 Questions on Unit

- If you have any questions regarding damage to the unit, unknown parts or for general inquiries, please contact your ADT Co., Ltd. with the following information.

- (1) Inverter Model
- (2) Production Number (Serial No.)
- (3) Date of purchase
- (4) Reason for Calling
 - ① Damaged part and its condition etc.
 - ② Unknown parts and their contents etc.

1.2.2 Warranty for the unit

- (1) The warranty period of the unit is one year after the purchase date. However the warranty will be void if the fault is due to;
 - ① Incorrect use as directed in this manual, or attempted repair by unauthorized personnel.
 - ② Any damage sustained other than from transportation (Which should be reported immediately).
 - ③ Using the unit beyond the limits of the specifications.
 - ④ Natural Disasters : Earthquakes, Lightning, etc
- (2) The warranty is for the inverter only, any damage caused to other equipment by malfunction of the inverter is not covered by the warranty.
- (3) Any examination or repair after the warranty period (one-year) is not covered. And within the warranty period any repair and examination which results in information showing the fault was caused by any of the items mentioned above, the repair and examination costs are not covered. If you have any questions regarding the warranty, please contact either your ADT Co., Ltd..

2. Installation and Wiring

2.1 Installation

 CAUTION

- Be sure to install the unit on flame resistant material such as metal.
Otherwise, there is a danger of fire.
- Be sure not to place anything flammable in the vicinity.
Otherwise, there is a danger of fire.
- Do not carry the unit by the top cover, always carry by supporting the base of unit.
There is a risk of falling and injury.
- Be sure not to let foreign matter enter such as cut wire refuse, spatter from welding, iron refuse, wire, dust, etc.
Otherwise, there is a danger of fire.
- Be sure to install the inverter in a place which can bear the weight according to the specifications in the text.
Otherwise, it may fall and result in possible injury.
- Be sure not to install and operate an inverter which is damaged or parts of which are missing.
Otherwise, there is a danger of injury.
- Be sure to install the inverter in an area which is not exposed to direct sunlight and is well ventilated. Avoid environments which tend to be high in temperature, high in humidity or to have dew condensation, as well as places with dust, corrosive gas, explosive gas, inflammable gas, grinding-fluid mist, salt damage, etc.
Otherwise, there is a danger of fire.

2.1.1 Installation

- (1) **Transportation**
This inverter has plastic parts. So handle with care.
Do not over tighten the wall mounting fixings as the mountings may crack, causing is a risk of falling.
Do not install or operate the inverter if there appears to be damaged or parts missing.
- (2) **Surface for the mounting of inverter**
The temperature of the inverter heatsink can rise very high.
The surface, to which the inverter will be mounted, must be made of a non-flammable material(i.e. steel) due to the possible risk of fire. Attention should also be made to the air gap surrounding the inverter. Especially, when there is a heat source such as a breaking resistor or reactor.




Fig 2- 1 Surface for the mounting of inverter

- (3) **Operating Environment-Ambient Temperature**
The ambient temperature surrounding the inverter should not exceed the allowable temperature range (-10 to 50°C).
The temperature should be measured in the air gap surrounding the inverter, shown in the diagram above. If the temperature exceeds the allowable temperature, component life will become shortened especially in the case of the Capacitors.
- (4) **Operating Environment-Humidity**
The humidity surrounding the inverter should be within the limit of the allowable percentage range (20% to 90% / RH).
Under no circumstances should the inverter be in an environment where there is the possibility of moisture entering the inverter.
Also avoid having the inverter mounted in a place that is exposed to the direct sunlight.
- (5) **Operating Environment-Air**
Install the inverter in a place free from dust, corrosive gas, explosive gas, combustible gas, mist of coolant and sea damage.
- (6) **Mounting Position**
Mount the inverter in a vertical position using screws or bolts. The mounting surface should also be free from vibration and can easily hold the weight of the inverter.
- (7) **Ventilation within an Enclosure**
If you are installing one or more inverters in an enclosure a ventilation fan should be installed. Below is a guide to the positioning of the fan to take the airflow into consideration. The positioning of inverter, cooling fans and air intake is very important.
If these positions are wrong, airflow around the inverter decreases and the temperature surrounding the inverter will rise. So please make sure that the temperature around is within the limit of the allowable range.

2.2 Wiring

WARNING

- Be sure to ground the unit.
Otherwise, there is a danger of electric shock and/or fire.
- Wiring work should be carried out by qualified electricians.
Otherwise, there is a danger of electric shock and/or fire.
- Implement wiring after checking that the power supply is off.
Otherwise, there is a danger of electric shock and/of fire.
- After mounting the inverter, carry out wiring.
Otherwise, there is a danger of electric shock and/or injury.

CAUTION

- Be sure not to connect AC power supply to the output terminals(U, V, W).
Otherwise, there is a danger of injury and/or fire and/or damage to unit.
- Be sure to set an earth leakage breaker or the fuse(s) which is(are) the same phase as the main power supply in the operation circuit.
Otherwise, there is a danger of fire and/or damage to unit.
- As for motor leads, earth leakage breakers, and electromagnetic contactors, be sure to use equivalent ones with the specified capacity(rated).
Otherwise, there is a danger of fire and/or damage to unit.
- Do not stop operation by switching off the electromagnetic contactors on the primary or secondary sides of the inverter.
Otherwise, there is a danger of injury and/or machine breakage.

2.2.1 Terminal Connection Diagram (sink type)





Fig.2-2 Terminal Connection Diagram (sink type)

(1) Explanation of main circuit Terminals

Symbol	Terminal Name	Explanation of contents
R,S,T (RS)	Main power	Connect alternating power supply.
U,V,W	Inverter output	Connect three-phase motor.
P, RB	External braking resistor	Connect optional External braking resistor.
G	Inverter earth terminals	Grounding terminal.

Table 2-2 Explanation of main circuit terminals

(2) Control circuit Terminals

Signal	Terminal Symbol	Terminal name	Terminal function
Input signal	P24	Interface power	24VDC \pm 10%, 35mA
	6 (RS)	Intelligent Input Terminal	Contact input : Close : ON (operating) Open : OFF(stop) Minimum ON TIME :12ms or more
	5 (AT)	Forward run command(FW), Reverse run command(RV), multi-speed commands1-4(CF1-4), 2-stage accel/decel (2CH), Reset(RS), Terminal software lock(SFT), Unattended start protection(USP), Free run stop(FRS), Jogging operation(JG), External trip(EXT), 3 wires input(STA,STP,F/R), Up/Down(Up, Down), Local Keypad Operation(O/R), Local Terminal Input Operation(T/R), PID Integral Reset(PIDIR), PID Disable(PIDD)	
	4 (CF2)		
	3 (CF1)		
	2 (RV)		
	1 (FW)		
CM1	Common terminal for input or monitor signal		
Monitor signal	FM	Analog Monitor (Frequency, Current, Voltage)	Analog Frequency Meter
Frequency command signal	H	Frequency power	10VDC
	O	Frequency command power terminal (voltage)	0-10VDC, Input Impedance 50k Ω
	OI	Frequency command terminal (current)	4-20mA, Input Impedance 200 Ω
	L	Analog power common	
Intelligent relay output signal	AL0 AL1 AL2	Intelligent output signals : at normal status, power off : AL0-AL2 (closed) at abnormal status : AL0-AL1(closed)  Intelligent Output Signal(relay output) Run Signal(RUN), Frequency Arrival Signal (FA1), Frequency Arrival Signal (FA2), Overload Advance Notice Signal(OL), Output Deviation for PID Control(OD), Alarm Signal output(AL)	Contact rating: AC 250V 2.5A (resistor load) 0.2A (inductor load) DC 30V 3.0A (resistor load) 0.7A (inductor load)
Intelligent output signal	11	Intelligent Output Signal(Open Collector) Run Signal(RUN), Frequency Arrival Signal (FA1), Frequency Arrival Signal (FA2), Overload Advance Notice Signal(OL), Output Deviation for PID Control(OD), Alarm Signal output(AL)	24VDC, 50mA max
	12		
	CM2	Common terminal for output signal	

Signal	Terminal Symbol	Terminal name	Terminal function
No.1 channel communication terminal (RJ-45 terminal)	RXP	RJ-45 connector no.3 pin	Basic RS-485 Communication Terminal
	RXN	RJ-45 connector no.6 pin	
Safety signal input (Option)	SC	Safety signal input common terminal	Digital input terminal
	S2	Safety signal input normally close (NC) input terminal	
	S1	Safety signal input normally open (NO) input terminal	
No.2 channel communication terminal (Option)	R+	RS – 485 Communication + Terminal	No.2 channel RS-485 communication terminal (Option)
	R-	RS – 485 Communication - Terminal	

Table2-3 Control circuit Terminals

2.2.2 Main circuit wiring

The wiring of main circuit terminals for the inverter are in the following pictures.

Wiring of terminals	Corresponding type	Screw Size	Width (mm)																
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>R</td><td>S</td><td></td><td>RB</td><td>P</td><td>U</td><td>V</td><td>W</td> </tr> <tr> <td>(L1)</td><td>(L2)</td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>	R	S		RB	P	U	V	W	(L1)	(L2)							iMaster-E1-004SF iMaster-E1-007SF	M3	7.62
R	S		RB	P	U	V	W												
(L1)	(L2)																		
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>R</td><td>S</td><td>T</td><td>RB</td><td>P</td><td>U</td><td>V</td><td>W</td> </tr> <tr> <td>(L1)</td><td>(L2)</td><td>(L3)</td><td></td><td></td><td></td><td></td><td></td> </tr> </table>	R	S	T	RB	P	U	V	W	(L1)	(L2)	(L3)						iMaster-E1-004LF iMaster-E1-007LF iMaster-E1-015LF	M3	7.62
R	S	T	RB	P	U	V	W												
(L1)	(L2)	(L3)																	
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>R</td><td>S</td><td></td><td>RB</td><td>P</td><td>U</td><td>V</td><td>W</td> </tr> <tr> <td>(L1)</td><td>(L2)</td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>	R	S		RB	P	U	V	W	(L1)	(L2)							iMaster-E1-015SF iMaster-E1-022SF	M4	11
R	S		RB	P	U	V	W												
(L1)	(L2)																		
<table border="1" style="width: 100%; text-align: center;"> <tr> <td>R</td><td>S</td><td>T</td><td>RB</td><td>P</td><td>U</td><td>V</td><td>W</td> </tr> <tr> <td>(L1)</td><td>(L2)</td><td>(L3)</td><td></td><td></td><td></td><td></td><td></td> </tr> </table>	R	S	T	RB	P	U	V	W	(L1)	(L2)	(L3)						iMaster-E1-022LF iMaster-E1-037LF iMaster-E1-004HF iMaster-E1-007HF iMaster-E1-015HF iMaster-E1-022HF iMaster-E1-037HF	M4	11
R	S	T	RB	P	U	V	W												
(L1)	(L2)	(L3)																	

Table 2-4 Wiring of main circuit terminals

2.2.3 Terminal connection diagram

(1) Terminal connection diagram

- ① The control circuit terminal of inverters is connected with the control board in unit.




Fig 2-4 Terminal connection diagram

(2) Example of Main PCB terminal's wire




Fig 2-5 Example of Main PCB's wire

3. Operation

 **WARNING**

- Be sure not to touch the main terminal or to check the signal add or remove wires and/or connectors.
Otherwise, there is a danger of electric shock.
- Be sure not to turn the input power supply on until after front case is closed.
While the inverter is energized, be sure not to remove the front cover.
Otherwise, there is a danger of electric shock.
- Be sure not to operate the switches with wet hands.
Otherwise, there is a danger of electric shock.
- While the inverter is energized, be sure not to touch the inverter terminals even while the unit is not running.
Otherwise, there is a danger of electric shock.
- If the Restart Mode is selected, it may suddenly restart during the trip stop.
Be sure not to approach the equipment.(Be sure to design the equipment so that personnel safety will be secured even if equipment restarts.)
Otherwise, there is a danger of injury.
- Be sure not to select Restart Mode for up and down equipment or traveling equipment, because there is an output free-running mode in term of retry.
Otherwise, there is a danger of injury and/or machine breakage
- Even if the power supply is cut for a short period of time, the inverter may restart operation after the power supply is restored if the operation command is given.
If a restart may incur danger to personnel, be sure to make a circuit so that it will not restart after power recovery.
Otherwise, there is a danger of injury.
- The stop key is valid only when a function is on. Ensure that there is a hard wired emergency stop that is separate from the stop key of the inverter.
Otherwise, there is a danger of injury.
- With the operation command on, if the alarm reset is ordered, the inverter can restart suddenly. Be sure to set the alarm reset after checking the operation command is off.
Otherwise, there is a danger of injury.
- Be sure not to touch the inside of the energized inverter or to put a bar into it.
Otherwise, there is a danger of electric shock and/or fire.

4. Parameter Code List

4.1 About Digital Operator

4.1.1 Name and contents of each part of Standard-type digital operator

(1) Part name

RUN LED

on when the inverter outputs the PWM voltage and operating command is ready

UP/DOWN Key

This key is used to change data and increase of decrease the frequency

PRG LED

This LED is on when the inverter is ready for parameter editing.

Display part (LED display)

This part display frequency, motor current, motor rotation speed, alarm history, and setting value.

RUN Key

Press this key to run the motor. The Run enable LED must be terminal operation

FUNCTION Key

This key is used for changing parameter and command.



Hz LED / A LED

Display units Hertz/Amperre LEDs.

Potentiometer

set the inverter output frequency (be operated only when the ramp is ON)

STORE Key

Press the store key to write the data and setting value to the memory

STOP/RESET Key

This key is used for stopping the motor or resetting errors. (When either operator or terminal is selected, this key works. If the extension function b 15 is used, this function is void)

Fig.4-1 LED Type Digital Operator

Display description:

When the inverter is turned on, the output frequency monitor display appears.


(2) Operation procedure

① Key Description



② Extended function mode navigation map

Using the ▲ / ▼ key to enter the expanded function mode, select expanded Function command NO. in **R--**, **b--**, **C--** and **H--** mode.



③ Example that the frequency is set from potentiometer to the standard operator and the equipment starts running)

Submenu "d" – Display options

Ability to display several performance values of the drive (Pages 4-6 and 4-7)

Submenu "F" – Basic Function Modes

Ability to set basic speed and directional settings (Page 4-8)

Submenu "A" – Expanded Function Modes

Include basic controls and run commands (Pages 4-9 through 4-15)

Submenu "b" – Expanded (Fine Tuning) Functions

Electronic Thermal Overload, and Factory reset in this submenu (Pages 4-16 through 4-20)

Submenu "C" – Intelligent Terminal Functions

PLC and Input/Output Terminal options (Page 4-21 through 4-23)

Submenu "H" – Expanded Motor Performance Settings

Motor Poles, Auto Tuning, Sensorless Vector on/off (Page 4-24)

Sensorless Vector Control setup on pages 5-24


For Protective Functions and Fault Codes please see page 6-1

4.1.2 Key Definition and Operation of “SHIFT”

Definition : The “SHIFT” function is enable to press both up and down key simultaneously. The left most 7-segment digit is blinked and if press store key, the blinked segment moves to the right digit. When the ‘store’ key is pressed, it moved to the right digits again. When the right most digit is blinked and press the ‘store’ key, it turn back to the function code display.

1. Display digit movement

- Press the UP key and DOWN key at the same time in data setting mode.
→ Change Scroll-mode to Shift-mode



2. Data setting method

Stop in target group using UP/DOWN key → Press the function key, Change to data setting mode.

Press the UP key and DOWN key at the same time. → First number is flashing on the left

Change the data using UP/DOWN key → Press the Store-key
→ Third number is flashing



Change the data using UP/DOWN key → Press the Store-key
→ Second number is flashing

Change the data using UP/DOWN key → Press the Store-key
→ First number is flashing

Change the data using UP/DOWN key → Press the Store-key
→ Target function code is setting

4.2 Function List

4.2.1 Monitor Mode (d-group) Display



Func-code	Name	Description
d01	Output frequency monitor	Real-time display of output frequency to motor, from 0.00 to 400.0 Hz, "Hz" LED ON
d02	Output current monitor	Real-time display of output current to motor, from 0.0 to 999.9A, "A" LED ON.
d03	Output voltage monitor	Real-time display of output voltage to motor
d04	Rotation direction monitor	Three different indications: "F"..... Forward Run "□".... Stop "r"..... Reverse Run
d05	PID feedback monitor	Displays the scaled PID process variable (feedback) value (A50 is scale factor)
d06	Intelligent input terminal status	Displays the state of the intelligent input terminals:  단자대 NO. 6 5 4 3 2 1
d07	Intelligent output terminal status	Displays the state of the intelligent output terminals:  단자대 NO. AL 12 11
d08	RPM output monitor	0 ~ 65530 (RPM) (=120 x d01 x b14) / H04
d09	Power consumption monitor	0 ~ 999.9 (kW)
d10	Operating time accumulation monitor(hour)	0 ~ 9999 (hr)
d11	Real operating time monitor (minute)	0 ~ 59 (min)
d12	DC link voltage	0 ~ 999 (V)
d13	Trip event monitor	Displays the current trip event ·Display method Alarm reason ↓ press the UP key Output frequency at alarm event ↓ press the UP/DOWN key Output current at alarm event ↓ press the UP/DOWN key DC link voltage at alarm event ↓ press the FUNC key "d13" display ·No trip event
d14	Trip history 1 monitor	Displays the previous first trip event
d15	Trip history 2 monitor	Displays the previous second trip event
d16	Trip history 3 monitor	Displays the previous third trip event
d17	Trip count	Displays the trip accumulation count



4.2.2 Basic Function Mode of F Group




Func-code	Name	Run-time Edit	Description	Defaults
F01	Output frequency setting	✓	Standard default target frequency that determines constant motor that determines constant motor speed. units of 0.01Hz setting range is 0.00 to 400.0Hz. (In the case of sensorless vector control, setting range is 0.00 to 300.0Hz.) frequency setting from UP/DOWN key of digital operator.	0.00Hz
F02	Acceleration time1 setting	✓	0.1 ~ 3000sec Minimum setting range 0.1 ~ 999.9 --- by 0.1sec 1000 ~ 3000 --- by 1sec	10.0sec
F03	Deceleration time 1 setting	✓	0.1~3000sec Minimum setting range 0.1 ~ 999.9 --- by 0.1sec 1000 ~ 3000 --- by 1sec	10.0sec
F04	Rotation direction setting	X	Two options: select codes: 0... Forward run 1... Reverse run	0
A--	Extended function of A group setting	-	Basic setting functions setting range : A01 ~ A85.	-
b--	Extended function of b group setting	-	Fine tuning functions Setting range :b01 ~ b33	-
C--	Extended function of C group setting	-	Terminal setting functions Setting range :C01 ~ C24	-
H--	Extended function of H group setting	-	Sensorless vector setting functions Setting range :H01 ~ H11.	-



Note) If you set the carrier frequency less than 2kHz, acceleration / deceleration time delays approximately 500msec.


4.2.3 Expanded Function Mode of A Group


Func-code	Name	Run-time Edit	Description	Defaults
Basic parameter settings				
A01	Frequency command (Multi-speed command method)	X	Four options: select codes: 0.... Keypad potentiometer 1.... Control terminal input 2.... Standard operator 3.... Remote operator(communication) 4.... Remote operator2(IO Board) - Option	1
A02	Run command	X	Set the method of run commanding: 0.... Standard operator 1.... Control terminal input 2.... Remote operator(communication) 3.... Remote operator2(IO Board) - Option	1
A03	Base frequency setting	X	Settable from 0 to maximum frequency(A04) in units of 0.01Hz 	60.00Hz
A04	Maximum frequency setting	X	Settable from the base frequency [A03] up to 400Hz in units of 0.01 Hz. In the case of sensorless vector control, (A31=2) possible for driving to 300Hz	60.00Hz
Analog Input Settings				
A05	External frequency setting start (O, OI)	X	Start frequency provided when analog input is 0V (4mA) can be set in units of 0.01Hz setting range is 0 to maximum frequency(A04) 	0.00Hz
A06	External frequency setting end (O, OI)	X	End frequency provided when analog input is 10V (20mA) can be set in units of 0.01Hz. Setting range is 0 to maximum frequency(A04)	0.00Hz
A07	External frequency start rate setting (O, OI)	X	The starting point(offset) for the active analog input range(0~10V, 4mA~20mA) setting range is 0 to 100% in units of 0.1%	0.0%
A08	External frequency end rate setting (O, OI)	X	The ending point(offset) for the active analog input range(0~10V, 4mA~20mA) setting range is 0 to 100% in units of 0.1%	100.0%

Func-code	Name	Run-time Edit	Description	Defaults
A09	External frequency start pattern setting	X	Two options: select codes:  0--- start at start frequency 1--- start at 0Hz	0
A10	External frequency sampling setting	X	Range n = 1 to 8, where n = number of samples for average	4
Multi-speed Frequency Setting				
A11 ~ A25	Multi-speed frequency setting	✓	<ul style="list-style-type: none"> Defines the first speed of a multi-speed profile, range is 0 to maximum frequency(A04) in units of 0.01Hz. Setting range is 1-speed(A11) to 15-speed(A25). Speed0 : volume setting value 	speed1:5Hz speed2:10Hz speed3:15Hz speed4:20Hz speed5:30Hz speed6:40Hz speed7:50Hz speed8:60Hz etc. 0Hz
A26	Jogging frequency setting	✓	Defines limited speed for jog, range is 0.5 to 10.00Hz in units of 0.01Hz. The jogging frequency is provided safety during manual operation.	0.50Hz
A27	Jogging stop operation selection	X	Define how end of jog stops the motor: 0.... Free-run stop 1.... Deceleration stop(depending on deceleration time) 2.... DC injection braking stop (necessary to set DC injection braking)	0
V/F Characteristics				
A28	Torque boost mode selection	X	Two options: 0... Manual torque boost 1.... Automatic torque boost	0
A29	Manual torque boost setting	✓	Can boost starting torque between 0 and 50% above normal V/F curve, from 0 to 1/2 base frequency Be aware that excessive torque boost can cause motor damage and inverter trip. 	2.0%

Func-code	Name	Run-time Edit	Description	Defaults
A30	Manual torque boost frequency setting	✓	Sets the frequency of the V/F breakpoint A in graph for torque boost. Range is 0.0 to 100.0%	10.0%
A31	V/F characteristic curve selection	X	Two available V/F curves: three select codes: 0... Constant torque 1... Reduced torque(reduction of the 1.7th power) 2... Sensorless vector control 	004LF/HF ~037LF/HF : 0 004SF ~022SF : 2
A32	V/F gain setting	✓	Sets output voltage gain of the inverter from 20 to 110%. It is proper to set the voltage gain above 100% in case the rated output voltage is lower than the rated input voltage 	100.0%
DC Injection Braking Settings				
A33	DC injection braking function selection	X	Sets two options for DC injection braking 0.... Disable 1.... Enable	0
A34	DC injection braking frequency setting	X	The frequency at which DC injection braking occurs, range is 0.50 to 10.00 Hz in units of 0.01Hz	0.50Hz
A35	DC injection braking output delay time setting	X	The delay from the end of Run command to start of DC injection braking (motor free runs until DC injection braking begins). Setting range is 0.0 to 5.0sec in units of 0.1set. 	0.0sec
A36	DC injection braking force setting	X	Applied level of DC injection braking force settable from 0 to 100% in units of 0.1%	50.0%
A37	DC injection braking time setting	X	Sets the duration for DC injection braking, range is 0.0 to 10.0 seconds in units of 0.1sec.	0.0sec

Func-code	Name	Run-time Edit	Description	Defaults
Frequency-related Functions				
A38	Frequency upper limit setting	X	<p>Sets a limit on output frequency less than the maximum frequency(A04). Range is frequency lower limit(A39) to maximum frequency(A04) in units of 0.01Hz.</p> 	0.00Hz
A39	Frequency lower limit setting	X	<p>Sets a limit on output frequency greater than zero. Range is 0.00 to frequency upper limit(A38) in units of 0.01Hz</p>	0.00Hz
A40 A42 A44	Jump(center) frequency setting	X	<p>Up to 3 output frequencies can be defined for the output to jump past to avoid motor resonances (center frequency) range is 0.00 to maximum frequency(A04) in units of 0.01Hz..</p>	0.00Hz
A41 A43 A45	Jump(hysteresis) frequency width setting	X	<p>Defines the distance from the center frequency at which the jump around occurs. Range is 0.00 to 10.00Hz in units of 0.01Hz</p> 	0.00Hz

Func-code	Name	Run-time Edit	Description	Defaults
Automatic Voltage Regulation (AVR) Function				
A52	AVR function selection	X	Automatic (output) voltage regulation, selects from three type of AVR functions three option codes: 0... Constant ON 1... Constant OFF 2... OFF during deceleration The AVR feature keeps the inverter output waveform at a relatively constant amplitude during power input fluctuations	2
A53	Motor input voltage setting	X	220V class inverter settings: 200/220/230/240 380V class inverter settings: 380/400/415/440/460/480	220V/ 380V
Second Acceleration and Deceleration Functions				
A54	Second acceleration time setting	✓	Duration of 2nd segment of acceleration, range is 0.1 to 3000 sec. Second acceleration can be set by the [2CH] terminal input or frequency transition setting	30.0sec
A55	Second deceleration time setting	✓	Duration of 2nd segment of deceleration, motor range is 0.1 to 3000 sec. Second acceleration can be set by the [2CH] terminal input or frequency transition setting	30.0sec
A56	Two stage acce1/dece1 switching method selection	X	Two options for switching from 1st to 2nd accel/decel: 0.... 2CH input from terminal 1.... transition frequency 	0
A57	Acc1 to Acc2 frequency transition point	X	Output frequency at which Accel 1 switches to Accel 2, range is 0.00 to maximum frequency(A04) in units of 0.01Hz.	0.00Hz
A58	Decel 1 to Decel 2 frequency transition point	X	Output frequency at which Decel 1 switches to Decel 2, range is 0.00 to maximum frequency(A04) in units of 0.01Hz.	0.00Hz

Func-code	Name	Run-time Edit	Description	Defaults
A59	Acceleration curve selection	X	<p>Set the characteristic curve of Acc1 and Acc2, two options:</p> <p>0 --- Linear 1 --- S-curve (max. acceleration time : 39.0sec) 2 --- U-curve (max. acceleration time : 29.0sec)</p> 	0
A60	Deceleration curve setting	X	<p>Set the characteristic curve of dec1 and dec2, two options:</p> <p>0 --- Linear 1 --- S-curve (max. deceleration time : 39.0sec) 2 --- U-curve (max. deceleration time : 29.0sec)</p>	0
A61	Input voltage offset setting	✓	<p>Set the voltage offset for external analog signal input signal adjustment Range is -10.0 to 10.0 [%]</p>	0.0%
A62	Input voltage Gain setting	✓	<p>Set the voltage gain for external analog signal input signal adjustment Range is 0.0 to 200.0 [%]</p>	100.0%
A63	Input current offset setting	✓	<p>Set the current offset for external analog signal input signal adjustment Range is -10.0 to 10.0 [%]</p>	0.0%
A64	Input current Gain setting	✓	<p>Set the current gain for external analog signal input signal adjustment Range is 0.0 to 200.0 [%]</p>	100.0%
A65	FAN operation mode	X	<p>Se the FAN operation mode</p> <p>0 : always ON 1 : ON in the run time</p>	0

Func-code	Name	Run-time Edit	Description	Defaults
PID Control(Note1)				
A70	PID Function selection	X	Enables PID function and Feed Forward Function, three option codes: 0.... PID control disable 1.... PID control enable 2.... F/F control enable	0
A71	PID Reference	✓	Displays the PID reference. If parameter A72 = 2, Used to adjust the PID reference from UP/DOWN key 0.0 to 100.0% in units of 0.01%	0.00%
A72	PID Reference source	X	Four options : select codes: 0.... Keypad potentiometer 1.... Control terminal input 2.... Standard operator 3.... Remote operator(communication)	2
A73	PID Feed-back source	X	Selects source of PID, option codes: 0.... "O" (current input) 1.... "V" (voltage input)	0
A74	PID P gain	✓	Sets the proportional gain that is applied to the deviation between the reference and the feedback signal. 0.1 to 1000% in units of 0.1%	100.0%
A75	PID I gain	✓	Set the integral time to output the accumulated PID error value. 0.0 to 3600sec in units of 0.1sec	1.0sec
A76	PID D gain	✓	Sets the output value to the variation of the PID input. 0.00 ~ 10.00sec in units of 0.01sec	0.0sec
A77	PID Err limit	✓	Set the maximum/minimum PID input(error) as a percentage of the maximum error. 0.0 ~ 100.0% in units of 0.1%	100.0%
A78	PID Output high limit	✓	Set the maximum PID output as a percentage of the maximum output frequency (A04). -100.0 ~ 100.0% in units of 0.1%	100.0%
A79	PID Output low limit	✓	Set the minimum PID output as a percentage of the maximum output frequency (A04). When set to 0.00%, the low limit is disabled. -100.0% ~ 100.0% in units of 0.1%	0.0%

Func-code	Name	Run-time Edit	Description	Defaults
A80	PID Output reverse	X	Two options : select codes 0.... PID output reverse disable 1.... PID output reverse enable	0
A81	PID scale factor	X	PID scale factor (multiplier), 0.1 to 1000% in units of 0.1%	100.0%
A82	Pre PID frequency	X	0.0 to Max Frequency(A04) in units of 0.01Hz. When A82 equals "0", Pre-PID function is disabled.	0.00Hz
A83	Sleep frequency	X	0.00 to Max Frequency(A04) in units of 0.01Hz	0.00Hz
A84	Sleep delay time	X	0.0 to 30.0sec in units of 0.1sec	0.0sec
A85	Wake up frequency	X	Sleep frequency(A83) to Max Frequency(A04) in units of 0.01Hz	0.00Hz

Note 1) PID feedback control

The PID(Proportional, Integral, Differential) control functions can apply to controlling of fan, the air (water) amount of pump, etc., as well as controlling of pressure within a fixed value.

[Input method of target value signal and feedback signal]

Set the reference signal according to the PID reference setting method(A72).

Set the feedback signal according to analog voltage input (0 to 10V) or analog current input (4 to 20mA).

To use analog current [O-L] for the target value, set the [AT] terminal to ON.

[PID gain adjustment]

If the response is not stabilized in a PID control operation, adjust the gains as follows according to the symptom of the inverter.

- The change of controlled variable is slow even when the target value is changed. → Increase P gain [A74]
- The change of controlled variable is fast, but not stable. → Decrease P gain[A74]
- It is difficult to make the target value match with the controlled variable. → Decrease I time [A75]
- Both the target value and the controlled variable are not stable. → Increase I time [A75]
- The response is slow even when the P gain is increased. → Increase D time [A76]
- The response is not stabilized due to oscillation even when the P gain is increased. → Decrease D time [A76]

The figure below is a more detailed diagram of the PID control.







Fig4-1 PID diagram

4.2.4 Expanded function mode of b group

Func-code	Name	Run-time Edit	Description	Defaults
Restart Mode				
b01	Selection of restart mode	X	Select inverter restart method, four option codes: 0.... Alarm output after trip, no automatic restart 1.... Restart at 0Hz 2.... Resume operation after frequency matching 3.... Resume previous freq. after freq. matching, then decelerate to stop and display trip info. • Restart trip is over current, overvoltage and under voltage. • Over current and over voltage trip restart up to 3 times, under voltage trip restart up to 10time.	0
b02	Allowable instantaneous power failure time setting	X	The amount of time a power input under voltage can occur without tripping the power failure alarm. Range is 0.3 to 1.0sec. If under-voltage exists longer than this time, the inverter trips, even if the restart mode is selected. This function are depends on the machine and load conditions. Before using this function, the verification test must be performed.	1.0sec
b03	Reclosing stand by after Instantaneous power failure recovered	X	Time delay after under-voltage condition goes away, before the inverter runs motor again. Range is 0.3 to 10.0 seconds. 	1.0sec
Electronic Thermal Overload Alarm Setting				
b04	Electronic thermal level setting	X	Set a level between 20% and 120% for the motor rated current. setting range- $0.2 \times (\text{motor rated current}) \sim 1.2 \times (\text{motor rated current})$.	100.0%
b05	Electronic thermal characteristic, selection	X	Select cooling method for motor: 0....Cooling fan is mounted on the motor shaft (Self-cool) 1....Cooling fan is powered by independent source (Forced-cool) 	1

Func-code	Name	Run-time Edit	Description	Defaults
Overload Restriction				
b06	Overload overvoltage Restriction mode selection	X	Select overload or overvoltage restriction modes 0.... Overload, overvoltage restriction mode OFF 1.... Only overload restriction mode ON 2.... Only overvoltage restriction mode ON 3.... Overload overvoltage restriction mode ON	3
b07	Overload restriction level setting	X	Sets the level for overload restriction, between 20% and 200% of the rated current of the inverter, setting range $0.2x(\text{inverter rated current}) \sim 2.0x(\text{inverter rated current})$	180%
b08	Overload restriction constant setting	X	Set the deceleration rate when inverter detects overload, range is 0.1 to 10.0 and resolution is 0.1 	1.0sec
Software Lock Mode				
b09	Software lock mode selection	X	Prevents parameter changes, in four options, option codes: 0.... All parameters except b09 are locked when SFT from terminal is on 1.... All parameters except b09 and output frequency F01 are locked when SFT from terminal is ON 2.... All parameters except b09 are locked 3.... All parameters except b09 and output frequency F01 setting are locked	0

Func-code	Name	Run-time Edit	Description	Defaults
Other Function				
b10	Start frequency Adjustment	X	Sets the starting frequency for the inverter output, range is 0.50 to 10.00Hz in units of 0.01Hz	0.50Hz
b11	Carrier frequency setting	✓	Sets the PWM carrier frequency, range is 3kHz to 16.0kHz in units of 0.1kHz.	5.0kHz
b12	Initialization mode (parameters or trip history)	X	Select the type of initialization to occur, two option codes: 0.... Trip history clear 1.... Factory Default (exceptional data) b13 : Country code A53 : Rated Motor Voltage	0
b13	Country code for initialization(note1)	X	Select default parameter values for country on initialization, three options, option codes: 0.... Korean version 1.... European version 2.... US version	0
b14	RPM conversion factor setting	✓	Specify a constant to scale the displayed RPM for [d08] monitor, range is 0.01 to 99.99 in units of 0.01	1.00
b15	STOP key validity during terminal operation	X	Select whether the STOP key on the keypad is enabled, two option codes: 0.... stop enabled 1.... stop disabled	0
b16	Resume on FRS cancellation mode	X	Select how the inverter resumes operation when the free-run stop (FRS) is cancelled, two options: 0... Restart from 0Hz 1....Restart from frequency detected from real speed of motor	0
b17	Communication number	X	Sets the inverter address for communication, range is 1 to 32.	1
b18	Ground fault setting	X	Select the function and level of ground fault.. 0 : Do not detect ground fault.	0.0


note1) Code is changed when the country code

0 - A03:60.00, A04:60.00, A09:0, A18:60.00, A26:0.50, A31:0, 2(SF Model)

1 - A03:50.00, A04:50.00, A09:1, A18:50.00, A26:1.00, A31:2

2 - A03:60.00, A04:60.00, A09:1, A18:60.00, A26:0.50, A31:0, 2(SF Model)





Func-code	Name	Run-time Edit	Description	Defaults
Other Function				
b19	Speed Search Current Suppression Level	✓	Controls the starting current level during speed search motion on the basis of the motor rated current. The Current Suppression Level of the controller is set from 90 % to 180%	100%
b20	Voltage increase Level during Speed Search	✓	In case of the lower starting current level during speed search motion on the basis of the motor rated current, the increase level of the output voltage is set from 10 % to 300%	100%
b21	Voltage decrease Level during Speed Search	✓	In case of the higher starting current level during speed search motion on the basis of the motor rated current, the decrease level of the output voltage is set from 10 % to 300%	100%
b22	Speed decrease Level during Speed Search	✓	Controls the speed decrease level during speed search motion. The speed decrease level of the controller is set from 1.0 to 200.0% (Operator display : 10 ~ 2000)	100.0% (1000)
b23	Frequency match operation selection	✓	In case of inverter starting operation, the start frequency of the inverter can be selected as follows 0 : 0Hz Starting operation 1 : Frequency matching & start operation	0
b24	Failure status output selection by relay in case of failure	✓	In case of failure, the alarm relay operation can be selected as follows 0 : Inactive in case of low voltage failure 1 : Active in case of failure (Inactive in case of restart mode) 2 : Active in case of all failure occurred include LV failure 3 : Active in case of failure (In case of low voltage failure, automatic restart)	0
b25	Stop method selection	✓	You can choose the method of stopping the motor when the inverter is given a stop command during operation. 0 : a normal decelerating stop 1 : free-run stop	0
b27	Input phase loss	X	A function that detects phase loss in the input AC source. Detection is performed using the fluctuation in the main circuit's DC voltage. Also, in the case of degradation in the main capacitor it could be occurred where maintenance replacement is required. To set the detection time of input phase loss, "code b27" is used. (0 ~ 100 in sec) When b27 equals "0", input phase loss function is disabled.	10

Func-code	Name	Run-time Edit	Description	Defaults
Other Function				
b28	Communication time out setting	✓	This function detects communication time out in case of communication cut off. To set the detection time of time out, "code b28" is used. 0: No detect time out 1~60 : detect time out when communication cut off [Unit : second]	0
b29	Communication time out operation mode	✓	Set communication time out operation mode 0 : Always active 1 : Active in case of inverter is running	0
b30	Display code setting	✓	Set Initial display status of d1 ~d13 after power on. Set value 1 to 13 for d1 to d13.	1
b31	2 nd Communication Channel (option) baud rate setting	✓	Setting 2 nd 485 communication channel baud rate 1 : 2400bps 2 : 4800bps 3 : 9600bps 4 : 19200bps	3
BRD(Dynamic braking) Function				
b32	BRD selection	X	Three options: select codes: 0 : Invalid : BRD doesn't operate 1 : During run : valid (BRD operates.) During stop : invalid (BRD doesn't operate.) 2 : During run, stop, valid (BRD operates.)	1
b33	BRD using ratio	X	Sets the BRD using ratio, range is 0.0 to 50.0% in units of 0.1%. When inverter exceeds the usage ratio, a trip occurs. $\text{BRD using ratio(\%)} = \frac{(t1 + t2 + t3)}{100\text{sec}} \times 100$ 	10.0%

4.2.5 Expanded Function Mode of C Group

Func-code	Name	Run-time Edit	Description	Defaults
Input Terminal Function				
C01	Intelligent Input terminal 1 setting	X	Select function for terminal 1 <code> 0: Forward run command(FW) 1: Reverse run command(RV) 2: 1st multi-speed command(CF1) 3: 2nd multi-speed command(CF2) 4: 3rd multi-speed command(CF3) 5: 4th multi-speed command(CF4) 6: Jogging operation command(JG) 8: 2-stage acceleration/deceleration command(2CH) 9: Free-run stop command(FRS) 10: External trip(EXT) 11: Unattended start protection(USP) 12: Software lock function(SFT) 13: Analog input current/voltage selection signal(AT) 14: Reset(RS) 15: Start(STA) 16: Keep(STP) 17: Forward/reverse(F/R) 18: Remote control UP(UP) 19: Remote control DOWN(DOWN) 20: Local Keypad Operation(O/R) 21: Local Terminal Input Operation(T/R) 22: PID Integral Reset(PIDIR) 23: PID Disable(PIDD)	0
C02	Intelligent Input terminal 2 setting	X	Select function for terminal 2 <code>-see C01 parameter	1
C03	Intelligent Input terminal 3 setting	X	Select function for terminal 3 <code>-see C01 parameter	2
C04	Intelligent Input terminal 4 setting	X	Select function for terminal 4 <code>-see C01 parameter	3
C05	Intelligent Input terminal 5 setting	X	Select function for terminal 5 <code>-see C01 parameter	13
C06	Intelligent Input terminal 6 setting		Select function for terminal 6 <code>-see C01 parameter	14

Func-code	Name	Run-time Edit	Description	Defaults
Input Terminal Status				
C07	Input Terminal 1 a/b contact setting (NO/NC)	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
C08	Input Terminal 2 a/b contact setting (NO/NC)	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
C09	Input Terminal 3 a/b contact setting (NO/NC)	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
C10	Input Terminal 4 a/b contact setting (NO/NC)	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
C11	Input Terminal 5 a/b contact setting (NO/NC)	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
C12	Input Terminal 6 a/b contact setting (NO/NC)	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
Output Terminal Function				
C13	Intelligent terminal Relay output setting	X	Select function for terminal relay output 0... RUN(Run signal) 1.... FA1(Frequency arrival signal: command arrival) 2.... FA2(Frequency arrival signal: setting frequency or more) 3.... OL(Overload advance notice signal) 4.... OD(Output deviation for PID control) 5.... AL(Alarm signal)	5
C14	Intelligent open collector Output 11 setting	X	Select function for terminal 11 0... RUN(Run signal) 1.... FA1(Frequency arrival signal: command arrival) 2.... FA2(Frequency arrival signal: setting frequency or more) 3.... OL(Overload advance notice signal) 4.... OD(Output deviation for PID control) 5.... AL(Alarm signal)	1
C15	Intelligent open collector Output 12 setting	X	Select function for terminal 12 0... RUN(Run signal) 1.... FA1(Frequency arrival signal: command arrival) 2.... FA2(Frequency arrival signal: setting frequency or more) 3.... OL(Overload advance notice signal) 4.... OD(Output deviation for PID control) 5.... AL(Alarm signal)	0
C16	Output Terminal 11 a/b contact setting	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
C17	Output Terminal 12 a/b contact setting	X	Select logic convention, two option codes: 0.... a contact (normally open) [NO] 1.... b contact (normally close) [NC]	0
C18	Monitor signal selection	X	Select function for terminal FM, 3 options 0.... output frequency monitor 1.... output current monitor 2.... output voltage monitor	0

Func-code	Name	Run-time Edit	Description	Defaults
Output Terminal state setting				
C19	Analog meter gain adjustment	✓	Range is 0 to 250, resolution is 1	100.0%
C20	Analog meter offset adjustment	✓	Range is -3.0 to 10.0% resolution is 0.1	0.0%
Output Terminal related function				
C21	Overload advance notice signal level setting	X	<p>Sets the overload signal level between 50% and 200% resolution is 0.1%.0.5x(Inverter rated current) ~2.0x (Inverter rated current)</p> 	100.0%
C22	Acceleration arrival signal frequency setting	X	<p>Sets the frequency arrival setting thres-hold for the output frequency during acceleration. Setting range is 0.0 to A04, resolution is 0.01Hz</p> 	0.00Hz
C23	Deceleration arrival signal frequency setting	X	<p>Sets the frequency arrival setting threshold for the output frequency during deceleration, setting range is 0.00 to maximum frequency(A04) resolution is 0.01Hz</p> 	0.00Hz
C24	PID deviation level setting	X	<p>Sets the allowable PID loop error magnitude. Setting range is 0.0 to 100%, resolution is 0.01%</p> 	10.0%

4.2.6 Expanded Function mode of H Group

Func-code	Name	Run-time Edit	Description	Defaults
H01	Auto-tuning mode selection	X	Two States for auto-tuning function, option codes: 0... Auto-tuning OFF 1... Auto-tuning ON	0
H02	Motor data selection	X	Two selections, option codes: 0...Use standard motor data 1...Use auto-tuning data	0
H03	Motor capacity	X	00.4L : 220V / 0.5HP 00.7L : 220V / 1.0HP 01.5L : 220V / 2.0HP 02.2L : 220V / 3.0HP 03.7L : 220V / 5.0HP 05.5L : 220V / 7.5HP 00.4H : 380V / 0.5HP 00.7H : 380V / 1.0HP 01.5H : 380V / 2.0HP 02.2H : 380V / 3.0HP 03.7H : 380V / 5.0HP 05.5H : 380V / 7.5HP	-
H04	Motor poles setting	X	2/4/6/8 poles	4
H05	Motor rated current	X	Range is 0.1 – 50.0A	-
H06	Motor no-load current I ₀	X	Range is 0.1 – 50.0A	-
H07	Motor rated slip	X	Range is 0.01 – 10.0%	-
H08	Motor Resistance R1	X	Range is 0.001 - 30.00Ω	-
H09	Transient Inductance	X	Range is 0.01 – 200.0mH	-
H10	Motor Resistance R1	X	Range is 0.001 - 30.00Ω	-
H11	Transient Inductance auto turning data	X	Range is 0.01 – 200.0mH	-

5. Protective function

The various functions are provided for the protection of the inverter itself, but they may also protection function when the inverter breaks down.

Name	Cause(s)	Error Code
Over current protection	When the inverter output current exceeds the rated current by more than approximately 200% during the motor locked or reduced in speed. Protection circuit activates, halting inverter output.	E04
Overload protection (Electronic thermal Regenerative)	When the inverter output current causes the motor to overload, the electronic thermal trip in the inverter cuts off the inverter output.	E05
Over voltage protection	If regenerative energy from the motor or the main power supply voltage is high, the protective circuit activates to cut off the inverter output when the voltage of DC link exceeds the specification	E07
Communication error	Communication error between inverter and its operator. If the Reset signal persists for more than 4 seconds, it will occur.	E60
Under-voltage protection	When input voltage drops below the low-voltage detection level, the control circuit does not function normally. So when the input voltage is below the specification, the inverter output is cut off.	E09
Output short-circuit	The inverter output was short-circuited. This condition causes excessive current for the inverter, so the inverter output is turned off.	E04 or E34
USP error	The USP error is indicated when the power is turned on with the Inverter in RUN state. (Enabled when the USP function selected)	E13
EEPROM	The inverter output is cut off when EEPROM in the inverter has an error due to external noise, excessive temperature rise, or other factor	E08
External trip	When the external equipment or unit has an error, the inverter receives the corresponding signal and cuts off the output.	E12
Temperature trip	When the temperature in the main circuit increases due to cooling fan stop, the inverter output is cut off. (only for the model type with cooling fan)	E21
Ground fault	When ground fault is detected on running condition, the output is cut off.	E14
Inverter Overload	The power device IGBT is protected from over heat. The operating time of inverter is 1 minute with 150% load. The operating time is changed depending on carrier frequency, load, ambient temperature and power rating.	E17
Input phase loss	A function that detects phase loss in the input AC source. Detection is performed using the fluctuation in the main circuit's DC voltage. Also, in the case of degradation in the main capacitor it could be occurred where maintenance replacement is required.	E20
Cpu error	Inverter main CPU error. When this trip occurs, the inverter power must be turned off and after discharging completely, it can be turned on.	E11
Safety function (option)	Safety input signal is in active state. After removing the safety operation signal, the inverter can be reset. The safety operation pin is option.	E22
Braking resistor overload protection	When BRD exceeds the usage ratio of the regenerative braking resistor, the over-voltage circuit activates and the inverter output is switched off.	E06

6. Specification

6.1 Standard specification list

(1) 200V Class Specifications

Inverter Model		004SF	007SF	015SF	022SF	004LF	007LF	015LF	022LF	037LF
Max. Applicable motor (4P, HP) (Note1)		0.5	1.0	2.0	3.0	0.5	1.0	2.0	3.0	5.0
Rated capacity (kVA)	200V	1.0	1.7	2.4	3.8	1.0	1.7	2.4	3.8	5.9
	240V	1.2	2.1	2.9	4.6	1.2	2.1	2.9	4.6	7.1
Rated input voltage		Single-phase(2-wires) 200~240V±10%, 50/60Hz±5%				Three-phase(3-wires) 200~240V±10%, 50/60Hz±5%				
Rated output voltage (Note2)		Three-phase 200~240V (corresponding to input voltage)								
Rates output current (A)		3	5	7	11	3	5	7	11	17
Dynamic braking approx. % torque, short time stop	Regenerative control	BRD circuit built-in (The discharge resistance is optional)								
	Min. resistive to be connected (Ω)	50	50	50	50	50	50	50	50	35
Weight (Kg)		0.7	0.7	0.7	0.98	0.7	0.7	0.7	0.98	1.2
Protection Design		IP20								

(2) 400V Class Specifications

Inverter Model		004HF	007HF	015HF	022HF	037HF
Max. Applicable motor (4P, HP) (Note1)		0.5	1.0	2.0	3.0	5.0
Rated capacity (kVA)	380V	1.2	2.2	3.2	4.7	6.1
	480V	1.5	2.8	4.0	6.0	7.6
Rated input voltage		Three-phase(3-wires) 380~480V±10%, 50/60Hz±5%				
Rated output voltage (Note2)		Three-phase 380~480V (corresponding to input voltage)				
Rates output current (A)		1.8	3.4	4.8	7.2	9.2
Dynamic braking approx. % torque, short time stop	Regenerative control	BRD circuit built-in (The discharge resistance is optional)				
	Min. resistive to be connected (Ω)	180	180	180	100	100
Weight (Kg)		0.98	0.98	0.98	0.98	1.2
Protection Design		IP20				

(3) Common specification for 200V/400V class

Inverter model		Common specification for all model
Control system(Note5)		Space vector modulation PWM system
Output frequency range (Note3)		0.01 ~ 400Hz
Frequency accuracy (Note4)		Digital command $\pm 0.01\%$ for Max. frequency, analog frequency $\pm 0.1\%$ ($25 \pm 10 \text{ }^\circ\text{C}$)
Frequency resolving power		Digital setting : 0.01HZ, Analog setting : Max. frequency / 1,000
Voltage/frequency characteristic		V/f control (constant torque, reduced torque), free V/f control
Overload current rate		150%, 60sec
Acceleration/Deceleration		0.1 ~ 3000.0 sec (Director, curve setting)
DC Injection Braking		On starting and decelerating by stop command, inverter operates under operation setting frequency. Or inverter operates with external input (Breaking power, time, frequency can be set.)
Input Signal	Frequency	Operator Extend signal Setting by up/down key Input voltage : DC0 ~ +10V (Input impedance 50K Ω) Input current : 4 ~ 20mA (Input impedance 200 Ω)
	Run/Stop	Operator Extend signal Run / Stop key (Forward / Reverse function mode) Forward run / stop (1a connect, 1b selection possibility)
	Intelligent input terminal	FW(Forward), RV(Reverse), CF 1~4(Multi-speed bit 1~4), RS(reset), AT(Analog input change), USP(USP function) EXT(external trip), FRS(free-run stop), JG(jogging), SFT(software lock), STA(start), STP(keep), F/R(forward/reverse) UP(remote control UP), DOWN(remote control DOWN), O/R(Local Keypad Operation), T/R(Local Terminal Input Operation) PIDIR(PID Integral Reset), PIDD(PID Disable)
Output Signal	Frequency monitor	Analog meter (DC0~10V full scale. Max · 1mA) Output frequency, output current and output voltage
	Intelligent output terminal (Relay)	Run(Run signal), FA1(Frequency arrival signal), FA2(Frequency arrival signal), OL(Overload advance notice signal), OD(Output deviation for PID control)
	Intelligent output terminal (Open collector)	Run(Run signal), FA1(Frequency arrival signal), FA2(Frequency arrival signal), OL(Overload advance notice signal), OD(Output deviation for PID control)
Other functions		AVR function, curved accel/dec. profile, upper and lower limiters, 16-stage speed profile, fine adjustment of start frequency, BRD function carrier frequency change(0.5 to 16Khz), frequency jump, gain and bias setting, process jogging, electronic thermal level adjustment, retry function, trip history monitor, auto tuning, V/f characteristic selection, Speed Search automatic torque boost, frequency conversion display, USP function


Protection function		Over current, Over load(Electronic thermal), Over voltage, Communication error, Under voltage, Output short circuit detection, USP error, EEPROM error, External error, Ground fault, Over heat, Input phase loss CPU error, IOLT, Safety function, Braking resistor overload
Standard specification	Ambient temperature	-10~50℃
	Storage temperature	-20~60℃
	Ambient humidity	Below 90%RH (Installed with no dew condensation)
	Vibration	5.9m/s ² (0.6G). 10~55Hz
	Location	Under 1000m above sea level, indoors (Installed away from corrosive gasses dust)
Option		Noise filter , DC reactor, AC reactor Remote operator, cable for remote operator, Braking resistor

Footnotes for the preceding tables


- The applicable motor refers to ADT Co., Ltd. standard 3-phase motor.
To use other motors, care must be taken to prevent the rated motor current from exceeding the rated output current of the inverter.
- The output voltage decreases as the main supply voltage decreases (except for use of the AVR function).
In any case, the output voltage cannot exceed the input power supply voltage.
- To operate the motor over 50/60Hz, consult the motor manufacturer about the maximum allowable rotation speed.
- Inverter frequency could be exceeded 1.5Hz for the maximum frequency [A04] in the case of motor stabilization is required.
- Control method setting A31 to 2 (sensorless vector control) Selected, set carrier frequency (b11) more than 2.1kHz.
Using motor less than half of the rated capacity, you cannot get enough performance.
Multiple motors cannot be driven by sensorless vector control.

6.2 Dimension


(1) iMaster-E1-004LF/004SF/007LF/007SF/015LF model external dimension.(mm)



(2) iMaster-E1-015SF/004HF/007HF/015HF/022SF/022LF/022HF model external dimension.(mm)



(3) iMaster-E1-037LF/037HF model external dimension.(mm)



Model	W(Width) [mm]	W1 [mm]	H(Height) [mm]	H1 [mm]	D(Depth) [mm]	Ø [mm]	Weight [kg]
iMaster-E1 004 SF	68	58	128	120	128	4.2	0.7
iMaster-E1 007 SF	68	58	128	120	128	4.2	0.7
iMaster-E1 015 SF	108	96	128	120	142	4.2	0.7
iMaster-E1 022 SF	108	96	128	120	142	4.2	0.98
iMaster-E1 004 LF	68	58	128	120	128	4.2	0.7
iMaster-E1 007 LF	68	58	128	120	128	4.2	0.7
iMaster-E1 015 LF	68	58	128	120	128	4.2	0.7
iMaster-E1 022 LF	108	96	128	120	142	4.2	0.98
iMaster-E1 037 LF	140	128	128	120	147	4.2	1.22
iMaster-E1 004 HF	108	96	128	120	142	4.2	0.98
iMaster-E1 007 HF	108	96	128	120	142	4.2	0.98
iMaster-E1 015 HF	108	96	128	120	142	4.2	0.98
iMaster-E1 022 HF	108	96	128	120	142	4.2	0.98
iMaster-E1 037 HF	140	128	128	120	147	4.2	1.22

